



ARDON

TECHNICAL DATA SHEET

KINGWIN S3 SRC CI

Safety shoes

Article NO: G3289

Upper: buffalo leather
Sole: PU/PU



Size: 36 - 48

Leather ankle boots with composite toecap and kevlar insole, hydrophobic finish and thermal insulation.

Type and degree of protection:

| Category | EN ISO 20345 |
|---|--------------|
| Antistatic properties | x |
| Absorption of energy in the heel area | x |
| Sole with pattern- oil resistance | x |
| Water resistance | x |
| Puncture resistance (kevlar insole) | x |
| Composite toecap for toe protection | x |
| CI - Cold insulation | x |
| Slip resistant ceramic tile floor with SLS and on steel floor with glycerol (SRC) | x |



This personal protective equipment is in conformity with this harmonized European Standard:

EN ISO 20345:2011: Personal protective equipment- Safety shoes. Slip resistance on ceramic tile floor with SLS and on steel floor with glycerol (SRC mark).



ARDON®

Certified by notified body no. 0193 (Prüf-und Forschungsinstitut Pirmasens e. V - Marie-Curie-Str. 19 - DE 66953 Pirtmasems), Certificate number 2000447 02 86.

| | |
|------------------|-----------------------|
| Pairs in carton: | 10 |
| Carton weight: | 19,0 kg |
| Carton size: | 0,0894 m ³ |

The shoes have to be perfect as for from and size, because they have rigid parts. The right size has to be found by measuring practically and carefully the shoes. The closing system has to be used correctly. The laces have to be tightened well without leaving too long free tops. The shoes have to be cleaned and treated with right, specific products, following the instructions for use. Do not keep footwear near heatings when not used and let them dry in a windy or room temperature. Before wearing and when cleaned, the shoes have to be controlled in order to find out visible defects existing, like closing system function, outsole profile's water, possible damages, etc. To define the right type of footwear to wear in every environment, the possible dangers and the place/ environment have to be indeded (e.g. construction industry, high temperatures, etc.). The shoes have to be stored correctly, keeping them in the proper packing.
